


Parts List & Assembly Instructions

(8) 6m X 2 7/8" leg bolts



(8) 6m nuts for leg assy



(8) 1/4" X 1" washers for leg assy



(8) 1/4" lock washers for leg assy



(1) allen wrench to tighten leg bolts



(1) wrench to tighten leg bolt nuts



Need Help? Please contact us:

Nilo Toys

800-872-6456

760-930-9180

www.nilotoys.com

Assemble legs onto table as shown.

